











Task Card - Cleaning

DO NOT UNDERTAKE THIS TASK UNLESS YOU HAVE BEEN INSTRUCTED IN ITS EXECUTION

TASK	Nanocyn Fumigation	
SCOPE	Process for fumigation of Nanocyn	
EQUIPMENT REQUIRED	Dynafoog fumigation machine	Nanocyn Disinfectant
SUPPORTING REFERENCES	Nanocyn Safety Data Sheet	

PPE REQUIREMENTS – Verify all PPE is in good condition prior to use

Foot Protection	Hearing Protection	High Visibility	Head Protection	Eye Protection	Hygiene Controls	Hand Protection	Protective Clothing	Disposable Mask	Sun Protection
 <input type="checkbox"/>	 <input type="checkbox"/>	 <input type="checkbox"/>	 <input type="checkbox"/>	 <input type="checkbox"/>	 <input type="checkbox"/>	 <input type="checkbox"/>	 <input type="checkbox"/>	 <input checked="" type="checkbox"/>	 <input type="checkbox"/>
OTHER	WHERE NANOCYN IS USED IN AN INFECTIOUS DISEASE ENVIRONMENT ENSURE PPE IS USED ACCORDINGLY								

KEY HAZARD AND RISK CONTROLS – Safety, Environment and General

- **SAFETY** – Use safety signs to indicate fumigation is in process
- **SAFETY** – Take care to avoid spillage when filling machine
- **SAFETY** – Review SDS of Nanocyn prior to use
- **GENERAL** – DO NOT fumigate directly into socket or electrical outlets

BEFORE YOU START TAKE 5 FOR SAFETY				
STOP and think about the potential dangers of the task and work area	LOOK and identify new hazards, and report these to the manager	ASSESS the risk, consider any possible threats of damage or injury	CONTROL hazard with suitable control measure to reduce risk	DO the task and monitor hazards by keeping a look out for changes

STEP BY STEP GUIDE	
STEP 1	<p>Preparation</p> <ul style="list-style-type: none"> Place the safety sign indicating wet floors / work in progress outside the room to be fumigated. Damp wipe any surfaces prior to fumigation to ensure surfaces are clean. Inspect machine for any visible damage. Ensure fumigation machine is switched "OFF" Open filling lid of fumigation machine. Open Nanocyn 5l container Slowly fill machine with required amount of Nanocyn, avoiding spilling. A funnel might be used if required. Do not overfill the machine, maximum capacity 4l. Close the 5l Nanocyn container and close fumigation machine lid Plug-in machine to a suitable power socket closest to the area to be fumigated.
STEP 2	<p>Fumigation</p> <ul style="list-style-type: none"> Wipe down any visible dust using standard cleaning processes. Set machine on "Max" setting Open blue adjustable tilt locking knob on left side Turn machine on using the "ON" Button Start dispensing Nanocyn by directing the machine towards the ceiling where the wall meets the ceiling. Slowly turn the machine along wall/ceiling junction to achieve an even coverage. Slow hand movements with slight twist and turns is all what is required, no need to walk into every corner. Let the machine do the job. Continue to slowly move the machine up and the walls in a slow "paining motion". Point the machine low to spray under tables, chairs if required. Once the room has been covered with the required amount of product turn the machine OFF. Lock the adjustable tilt knob. Unplug the machine and let the mist settle on all surfaces. Dry any areas by hand which need to be used immediately, otherwise let the product air dry on all surfaces. Move on to the next target area.
STEP 3	<p>Finish Up</p> <ul style="list-style-type: none"> Ensure hard surface floors are dry before removing wet floor signs. Return remaining Nanocyn into the 5L container if required or leave in machine.

EMERGENCY REQUIREMENTS
<ul style="list-style-type: none"> Be aware of site emergency response provisions and first aid requirements

FINAL CHECK
<ul style="list-style-type: none"> Are all work areas clean and tidy? Have you put all equipment and materials away neatly? Have you reported any near misses or incidents?